



Spout 88514 & 80135 must use spout adaptor 10637 and hold down nut 11894, all other spouts use spout adaptor 80639.

340 Series Parts List

Item	Part #	Description
1	11801	Coupling Nut
2	15208	Lock Nut
3	14021	Putty Gasket
4	12639	Seat
5	80037	Washer Type Stem Ass'y - Hot
6	80038	Washer Type Stem Ass'y - Cold
7	80349	Hot Handle Ass'y
8	12274	O-Ring
9	13717	Fibre Washer
10	80079	Washerless Stem Ass'y - Hot
11	80080	Washerless Stem Ass'y - Cold
12	80387	Acrylic Handle Ass'y - Hot
13	80388	Acrylic Handle Ass'y - Cold
14	88184	Wrist Handle Ass'y - Hot
15	88185	Wrist Handle Ass'y - Cold
16	80034	Gooseneck Spout Assembly
17	88546	12" Laundry Spout Assembly
18	80163	8" Laundry Spout Assembly
19	80601	Chrome Hose Adapter
20	80166	6" Laundry Spout Assembly
21	80639	Laundry Spout Adapter - Chrome
22	12271	O-Ring
23	80350	Cold Handle Assembly
24	88514	Hi-Rise Spout Assembly
25	80135	Cast Spout Assembly
26	10637	Kitchen Spout Adapter
27	11894	Hold Down Nut

For more information contact:

UNION BRASS MANUFACTURING COMPANY

2955 Lone Oak Circle, Eagan, MN 55121

Phone (651) 454-8858 Fax (651) 454-1228

WWW.UNIONBRASS.COM